


**LEISTER**

®

# ASTRO



Leister Technologies AG  
Galileo-Strasse 10  
CH-6056 Kaegiswil/Switzerland  
Tel. +41 41 662 74 74  
Fax +41 41 662 74 16  
[www.leister.com](http://www.leister.com)  
[sales@leister.com](mailto:sales@leister.com)



Read the operating instructions carefully before starting the device and keep them for future reference.

## Leister ASTRO Automatic Wedge Welding Machine

### Application

The Leister ASTRO is an automatic wedge welding machine for overlap welding of geomembrane liners in earthwork and civil engineering.

- Thermoplastic geomembrane liners: Polyethylene PE-HD, PE-LD, Polypropylene PP.
- Type of seam: Welding seams are produced in accordance with DVS 2225 part I and BAM.

Other dimensions are possible on request.

DVS: German Welding Society for welding

BAM: Federal Institute for Materials Research and Testing, Berlin.



### Warning



Danger! Unplug the tool before opening it as live components and connections are exposed.



Incorrect use of the hot wedge tool can present a fire and explosion hazard especially near combustible materials and explosive gases.



Do not touch the element housing and wedge when hot as they can cause burns. Allow the tool to cool down. Do not point the hot air flow in the direction of people or animals.



Connect the tool to a socket outlet with protective earth conductor. Any interruption of the protective earth conductor within or outside the tool is dangerous! Use only extension cables with a protective earth conductor!



Risk of entanglement! Do not touch pressure rollers when closing or during operation.



## Caution



The voltage rating stated on the tool should correspond to the mains voltage. In the case of a power loss, disengage the hot wedge.



For personal protection, we strongly recommend the tool be connected to an RCCB (Residual Current Circuit Breaker) before using it on construction sites.



The tool must be operated under supervision. Radiant heat from the hot wedge can ignite flammable materials. The device machine may only be used by qualified specialists or under their supervision. Children are not authorized to use this device.



Protect the tool from damp and wet.

## Conformity

Leister Technologies AG, Galileo-Strasse 10, CH-6056 Kaegiswil/Switzerland confirms that this product, in the version as brought into circulation through us, fulfils the requirements of the following EC directives.

Directives: 2006/42, 2004/108, 2006/95, 2011/65

Harmonised standards: EN 12100-1, EN 12100-2, EN 14121-1  
EN 55014-1, EN 55014-2, EN 61000-6-2,  
EN 61000-3-2, EN 61000-3-3,  
EN 62233, EN 60335-2-45, EN 50581

Kaegiswil, 29.08.2012

Bruno von Wyl, CTO

Beat Mettler, COO

## Disposal




Power tools, accessories and packaging should be sorted for environmental-friendly recycling. Only for EC countries: Do not dispose of power tools into household waste! According to the European Directive 2002/96 on waste electrical and electronic equipment and its incorporation into national law, power tools that are no longer suitable for use must be separately collected and sent for recovery in an environmental-friendly manner.

## Technical data


Voltage	V~	200, 230 (mains voltage is not reversible)
Frequency	Hz	50/60
Power consumption	W	1800
Temperature	°C / °F	max. 420 / 788
Welding pressure	N / lbs	max. 1500 / 337
Drive	m/min / feet	0.8– 5.0 / 2.6 – 16.5
Overlap width	mm / Inch	max. 150 / 5.9
Thickness of material	mm / mil	1.5 – 3.0
Noise emission level	LpA (dB)	< 71
Size L×W×H	mm	475 × 355 × 315
Weight	kg / lbs	23 / 50
Conformity mark		
Protection class I		<b>1</b>

Technical data and specifications are subject to change without prior notice.

## Description of machine



- 1 Power supply cord
- 2 Cable clip
- 3 Housing of electronics
- 4 Main switch
- 5 Display
- 6 Keyboard
- 7 Motor/ Drive
- 8 Hot wedge
- 9 Lever
- 10 Adjustment screw for welding pressure
- 11 Locking spring of adjustment screw
- 12 Carrying handle / Guide handle
- 13 Front wheel
- 14 Back wheel
- 15 Foil guide
- 16 Cable conduit for hot wedge
- 17 Pinch roller
- 18 Front guide roller
- 19 Rear guide roller
- 20 Lower drive/pressure roller
- 21 Upper drive/pressure roller
- 22 Adjustment screw for swivel head
- 23 Chain guard of lower part
- 24 Chain guard of tension arm
- 25 Chain guard of gear case



## Functional description


- Heating system → The hot air temperature is steplessly adjustable and electronically controlled. It is a floating hot wedge. (Illustration A).
- Welding pressure → infinitely variable (steplessly adjustable). The welding pressure is transmitted via a toggle lever to the pressure rollers. The swivel head guarantees the equalization of the pressure to both welded sections (c and d) as well as on a welded seam without test channel (Illustration B). This allows T-joints to be welded easily. During the welding process the pressure adjusts itself linearly to the change in material thickness of the geomembrane liners.
- Drive → The welding speed is adjustable and electronically controlled in steps of 0.1 m/min/feet. Digital display of SET and ACTUAL values. The power transmission works through a three stage planetary gear.

## Adjusting the hot wedge

Adjusting of the guide rollers for the requested material thickness (Illustration A).

- Adjustments may only be made to the hot wedge (8) after it has cooled down.
- Engage the automatic wedge-welding machine on the geomembrane liner or film to be welded.
- Stretch the lever (9) (Illustration C).
- Loosen the hexagon cap screw of the rear guide roller (19).
- The distance between the hot wedge (8) and the rear guide roller (19) should be the thickness of the material and the sharp tongue of the wedge should lie centrally to the pressure rollers (20/21).
- Tighten the hexagon cap screw of the rear guide roller (19).
- Loosen the hexagon cap screw of the front guide roller (18).
- The distance between hot wedge (8) and front guide roller (18) should be about 1 mm.
- Tighten the hexagon cap screw of the front guide roller (18).

Illustration A / Cross-section diagram of hot wedge system



- 8 Hot wedge
- 9 Lever
- 17 Pinch roller
- 18 Front guide roller
- 19 Rear guide roller
- 20 Lower drive/pressure roller
- 21 Upper drive/pressure roller
- 22 Adjustment screw for swivel head
- 23 Chain guard of lower part
- 24 Chain guard of tension arm
- 25 Chain guard of gear case
- 26 Fastening screw for hot wedge

Illustration B / Cross sectional diagram of an overlap weld





Illustration C



## Welding parameter

### Welding pressure

- Insert the two strips of the material to be welded between the lower drive-/pressure roller (20) and the upper drive/pressure roller (21) by approx. 5 mm (Illustration E). Pull the lever (9) (Illustration C). The hot wedge is automatically pushed forward. Push and hold down the locking spring (11). Turn the adjustment screw for welding pressure (10) until the drive/pressure rollers (20/21) slightly touch the material to be welded. Let go the locking spring (11) and release the tension of the lever (9).
- Keep pushing the locking spring of the adjustment screw (11). Adjust the welding pressure by turning the corresponding adjustment screw (10) according to illustration D and let go the locking spring (11) at the requested welding pressure.
- Warning: If the maximum welding pressure of 1500 N is exceeded mechanical damage may occur.

Illustration D




Illustration E







Illustration C





### Welding temperature

- Set the welding temperature with the keys. The temperature is dependent on the material and the ambient temperature. The in-put SET value will be shown on the display. Switch on the heating by pressing the and keys simultaneously. Heating up time approx. 5 mins.



### Welding Speed


- According on the film or geomembrane liner and the influence of the weather, set the welding speed with the keys. The in-put SET value will be shown on the display.






## Welding preparation

- Laying Width of overlap is about 80mm to 130mm. Geomembrane liners must be clean between the overlap as well as above and below.
  - Mains supply At least 3kW(generator supplied with an RCCB)
  - Cable to mains A minimum cable cross section in accordance with the table.
- |           |                                  |
|-----------|----------------------------------|
| 200–230V~ | to 50 m 3 × 1.0 mm <sup>2</sup>  |
|           | to 100 m 3 × 2.5 mm <sup>2</sup> |
| 120V~     | to 50m 3 × 1.5 mm <sup>2</sup>   |
|           | to 100 m 3 × 2.5 mm <sup>2</sup> |

## Operating conditions

- Before putting into operation, check power supply cord (1) and connector as well as extension cable for electrical and mechanical damage. Do not operate the equipment if damage is found.
-  Connect the equipment to nominal voltage. The nominal voltage indicated on the equipment must correspond to the mains voltage. In the case of a power loss, disengage the hot wedge (8).
- Start the device with Main- or Control-Level.

Main - Level	Control - Level
 <p>1 Speed ACTUAL value 2 Speed SET value 3 Temperature ACTUAL value 4 Temperature SET value 5 Voltage display ACTUAL value</p>	 <p>1 Speed ACTUAL value 2 Speed Power consumption in % 3 Temperature ACTUAL value 4 Temperature Power consumption in % 5 Voltage display ACTUAL value</p>
<div style="background-color: black; color: white; padding: 5px; display: inline-block;"> <b>&lt; Overload indication * Heating / Drive active</b> </div>	
	

- Check the welding process and identify faults by means of the display of power consumption.

Display 4	Heating reason for fault after heating up time
100 %	• mains under-voltage
Display 2	Drive reason for fault
100 %	• mains under-voltage
100 % or <	• overlap of the geomembrane liner too wide
100 % or <	• dirt on the drive rollers (20/21)
100 % or <	• max. welding pressure (1500 N) has been exceeded
100 % or <	• high welding speed with large sudden overload (ie anchoring trench, joints....)
If malfunction does not disappear, contact service center	




## Test Weld



- **WARNING:** Welding parameters must be verified by means of test welds before the welding operation is performed.
- Perform test weld as per the welding instructions of the material manufacturer and national standards, directives or start parameters as shown in the table.

HD - PE (material thickness in mm)			
1.5	2.0	2.5	3.0
420 °C	420 °C	420 °C	420 °C
5.0 m/min.	4.5 m/min.	4.2 m/min.	4.0 m/min.
1250 N	1500 N	1500 N	1500 N

## Welding

- Check:
  - Drive/ Pressure rollers (20/21) as well as the hot wedge (8) must be clean before engaging into the geomembrane liner or film.
  - Cable length/Cable guide.
- Adjust welding parameters, see page 15.
- The welding temperature must be achieved.
- Guide and position the automatic welding machine into the over-lapped geomembrane liner or film.
- Switch on drive motor with  key on keyboard (6).
- Pull the lever (9).

### Beginning of welding process

- Check the welded seam (wash/seam thickness reduction). As required, adjust the welding speed with   keys on keyboard (6).
- The automatic welding machine is guided along the overlap with the carrying handle/guide handle (12), so that the frontal width of the overlap is kept within the 22mm zone (see illustration F).

### Illustratio


#### 15 Foil guide

21 Upper drive/pressure roller  
(a 50mm or 45mm)




23 Chain guard of lower part

b Max. frontal width of  
a overlap

a 50 mm = b 22 mm



### End of welding process

- Release the tension lever (9) 1 cm before the end of the welded seam.
- Switch off the drive motor with key  on the keyboard (6). Switch off the heating by pressing the  and  keys on the keyboard (6) simultaneously.



After completion of the welding work, allow the hot wedge (8) to cool down and remove the power supply cord from the mains socket.

## Transport

- Use the storage case included in delivery when transporting the ASTRO hot-wedge welding machine. The storage case is equipped with a carrying handle.



Do not use the handles of the storage case, the tension lever (9) and handle /guide handle (12) of the automatic hot-wedge welding machine for transport by crane.

Use the carrying handle / guide handle (12) to lift the automatic hot-wedge welding machine by hand.



Allow the hot-wedge (8) to cool down before transport.

## Training

- Leister Technologies AG and its authorised Service Centres offer free welding courses and training. Informationen below [www.leister.com](http://www.leister.com).

## Accessories

- Only Leister accessories should be used

## Maintenance

- Check power supply cord (1) and plug for electrical and mechanical damage.
- Clean hotwedge (8) with a copper brush.
- Clean drive and pressure rollers (20/21) with a wire brush.
- Treat chain (22) with a suitable spray as required (chain guard 23/24).
- Check whether rollers (13/14/17/18/19) are running smoothly.

## Service and repair

- The tool should be checked by an authorized Service Center if the following message appears on the display (5): «maintenance; servicing».
- Repairs should only be carried out by authorised Leister Service Centres. They guarantee a correct and reliable repair service within reasonable period, using original spare parts in accordance with the circuit diagrams and spare parts lists.

## Warranty

- For this tool, we generally provide a warranty of one (1) year from the date of purchase (verified by invoice or delivery document). Damage that has occurred will be corrected by replacement or repair. The electrical hot-wedge is excluded from this warranty
- Additional claims shall be excluded, subject to statutory regulations.
- Damage caused by normal wear, overloading or improper handling is excluded from the guarantee.
- Warranty claims will be rejected for tools that have been altered or changed by the purchaser.



© Copyright by Leister

Your authorised Service Centre is:



Leister Technologies AG  
Galileo-Strasse 10  
CH-6056 Kaegiswil/Switzerland  
Tel. +41 41 662 74 74  
Fax +41 41 662 74 16  
[www.leister.com](http://www.leister.com)  
[sales@leister.com](mailto:sales@leister.com)

BA ASTRO / 05.2002 / 08.2012 / 18.02.2016  
Artikel Nr. 132.207